

Exterior Painting Scope of Work

Red Shakes:

1. Power wash all Red Shakes and prep for painting - taping off adjacent areas to protect from overspray and drips.
2. Protect all surfaces in and around the area where work is to be performed, including shrubs and landscaping.
3. Caulk any split or open joints before painting.
4. Paint all Red Cedar Shakes to match the gazebo with Sherwin-Williams Duration VinylSafe Exterior Acrylic Latex. **(Color – Smooth Bark SWVS #336)**

Brown Lap Siding:

1. Power wash all Brown Lap siding and prep for painting - taping off adjacent areas to protect from overspray and drips.
2. Protect all surfaces in and around the area where work is to be performed, including shrubs and landscaping.
3. Caulk any split or open joints before painting.
4. Paint all Brown Lap Siding with Sherwin-Williams Duration Exterior Acrylic Latex **(Color Match: Timber Bark) ** Sherwin has the exact match**

Cream Cement Hardie Siding:

1. Power wash all Cream siding and prep for painting - taping off adjacent areas to protect from overspray and drips. Protect all surfaces in and around the area where work is to be performed, including shrubs and landscaping.
2. Caulk any split or open joints before painting, and make small repairs on cracks/ nail pops on Hardie Panels
3. Paint all the Cream Hardie Siding with Sherwin-Williams Duration Exterior Acrylic Latex. **(Color Match: Autumn Tan) ** Sherwin has the exact match**

Ivory White Hardie Trim/ Edging:

1. Power wash all Trim and prep for painting - taping off adjacent areas to protect from overspray and drips.
2. Protect all surfaces in and around the area where work is to be performed, including shrubs and landscaping.
3. Caulk any split or open joints before painting, and make small repairs on cracks/ nail pops on Hardie Panels
4. Paint all Hardie Trim with Sherwin-Williams Duration Exterior Acrylic Latex. **(Color Match: Navajo Tan)**
****Sherwin has the exact match**

Prep and Paint Entry Handrails in front of the Building

1. Wire Brush and Prep (protect surrounding areas) Handrails in front of the building. Prime as needed.
2. Paint entry Handrails with Sherwin-Williams Pro Industrial DTM (Color Match)